



205 Frazier Road  
Altavista, VA 24517

Tel: +1 800-288-1804  
+1 434-369-4741

[schrader-bridgeport.com](http://schrader-bridgeport.com)

[ez-sensor.com](http://ez-sensor.com)



*Part No. 33000*  
**Vehicle Application Coverage**

*current as of December 2, 2010*

Form No. EZ-1001

Model	Year	Model	Year	Model	Year
<b>Buick</b>		Monte Carlo	2007 (clamp in)	Mustang	2007 - 2009
Allure	2007 - 2010	Monte Carlo	2007 (snap in)	Mustang	2010
Enclave	2008 - 2010	Silverado All	2007 (snap in)	Ranger	2007 - 2010
LaCrosse	2007 - 2010	Silverado All	2007 (TRW clamp in)		2008 - 2009
LeSabre	2007	Silverado All	2008 - 2010	Taurus	(banded)
Lucerne	2007 - 2010	Suburban All	2007 (snap in)	Taurus	2010
Rainier	2007	Suburban All	2007 (TRW clamp in)	Transit Connect	2010
Regal	2010	Suburban All	2008 - 2010	<b>GMC</b>	
<b>Cadillac</b>		Tahoe	2007 (snap in)	Acadia	2007 - 2010
CTS	2008 - 2010	Tahoe	2007 (TRW clamp in)	Envoy	2007 (clamp in)
DTS	2006 - 2010	Tahoe	2008 - 2010	Envoy	2008 - 2009
Escalade	2007 (snap in)	Traverse	2009 - 2010	Savana	2008 - 2010
Escalade	2007 (clamp in)	Uplander	2008 - 2009	Sierra All	2007 (snap in)
Escalade	2008 - 2010	Van	2008 - 2010	Sierra All	2007 (clamp in)
SRX	2007 - 2009	<b>Ford</b>		Sierra All	2008 - 2010
STS	2009 (clamp in)	Crown Victoria	2006 - 2008	Yukon All	2007 (snap in)
STS	2009 (snap in)	E-150	2007 - 2010	Yukon All	2007 (clamp in)
STS	2010	E-250	2007 - 2010	Yukon All	2008 - 2010
<b>Chevrolet</b>		E-350 SD	2007 - 2010	<b>Hummer</b>	
Avalanche All	2007 (snap in)	E-450 SD	2007 - 2010	H2	2008 - 2009
Avalanche All	2007 (TRW clamp in)	Edge	2007 - 2010	<b>Infiniti</b>	
Avalanche All	2008 - 2010	Escape	2005 - 2008	EX35	2008 - 2010
Aveo	2007 - 2010	Escape	2009 - 2010	FX35	2003 - 2010
Camaro	2010-2011	Explorer	2006 - 2010	FX45	2003 - 2008
Cobalt	2008	SportTrac	2006 - 2010	FX50	2009 - 2010
Cobalt	2009 (clamp in)	Expedition	2007 - 2010	G35	2003 - 2008
Cobalt	2009 (snap in)	Explorer	2006 - 2010	G37	2008 - 2010
Cobalt	2010	F-150	2007 - 2008	M35	2006 - 2011
Corvette	2010	F-150	2009 - 2010	M45	2003 - 2011
Equinox	2007 - 2010	F-250	2008 - 2010	Q45	2003 - 2006
Express	2008 - 2010	F-250	2009 - 2010	QX4	2003
HHR	2008	F-250 Super Duty	2008 - 2010	QX56	2004 - 2010
HHR	2009 (clamp in)	F-350	2009 - 2010	<b>Lexus</b>	
HHR	2009 (snap in)	F-350 Super Duty	2008 - 2010	ES 350	2007 - 2010
HHR	2010	F-450 Super Duty	2008 - 2010	GS 300	2005 - 2010
Impala	2006	Five Hundred	2006 - 2007	GS 350	2007 - 2010
Impala	2007 (clamp in)	Flex	2009 - 2010	GS 430	2005 - 2007
Impala	2007 (snap in)	Focus	2007 - 2010	GS 450H	2007 - 2010
Impala	2008 - 2010	Freestar	2006 - 2007	GS 460	2008 - 2010
Malibu	2009	Fusion	2007 - 2009	GX 470	2006 - 2010
Malibu	2008 (clamp in)	Fusion	2010	IS 250	2006 - 2010
Malibu	2008 (snap in)	Grand Marquis	2007 - 2010	IS 350	2006 - 2010
Monte Carlo	2006			IS C	2006 - 2010
				IS F	2006 - 2010

Titan	2004 - 2010	Land Cruiser	2005 - 2010
Versa	2007 - 2010	Matrix	2007 - 2010 (Japan)
Xterra	2003 - 2010	Matrix	2007 - 2010 (USA)
<b>Pontiac</b>		Prius	2006 - 2010
G3	2009 - 2010	RAV4	2006 - 2010
G5	2008 - 2010	Sequoia	2004 - 2008 (20 deg)
G6	2008 (clamp in)	Sequoia	2004 - 2008 (40 deg)
G6	2008 (snap in)	Sequoia	2009 - 2010
G6	2009 - 2010	Sienna	2006 - 2010
G8	2008 - 2009	Solara	2006 - 2010
Grand Prix	2007	Tacoma	2005 - 2010 (20 deg)
Grand Prix	2008 (clamp in)	Tacoma	2005 - 2010 (40 deg)
Grand Prix	2008 (snap in)	Tundra	2005 - 2010 (20 deg)
Montana	2008	Tundra	2005 - 2010 (40 deg)
Solstice	2008 - 2010	Venza	2009 - 2010
Torrent	2007 - 2009	Yaris	2008 - 2010
Vibe	2008-2010		
Wave	2008 - 2009		
<b>Saturn</b>			
Astra	2010		
Aura	2007		
Aura	2008 (clamp in)		
Aura	2008 (snap in)		
Aura	2009 - 2010		
Lambda	2007 - 2008		
Outlook	2007 - 2010		
Sky	2008 - 2009		
Vue	2007 - 2010		
<b>Scion</b>			
tC	2006 - 2010		
xB	2007 - 2010		
xD	2008 - 2010		
<b>Toyota</b>			
4 Runner	2004 - 2010		
Avalon	2007 - 2010		
Camry	2007 - 2010 (Japan)		
Camry	2007 - 2010 (USA)		
Camry Hybrid	2008 - 2010		
Corolla	2007 - 2010 (Japan)		
Corolla	2007 - 2010 (USA)		
FJ Cruiser	2008 - 2010		
Highlander	2007 - 2010		
Highlander Hybrid	2008 - 2010		

The Schrader® EZ-Sensor™ is assembled with a rubber snap-in style valve stem. Schrader® provides service packs to rebuild the sensor with a snap-in style valve stem or an aluminum clamp-in style valve stem.

**Service Pack** **Part No.**

**Rubber snap-in style valve stem** 20008



**Aluminum clamp-in style valve stem** 34000

